



Figure 1. Map of contamination area showing locations of bedrock monitoring wells, cone of depression from pump test in bedrock wells, and PCE plume in bedrock (all from NHDES, 2012), sites of resistivity surveys, and trace of Campbell Hill fault zone (from Figure 2). (Some wells omitted for clarity.)